


PHILIPS

NA55X





Contents

Important safety instruction	7
Recycling	9
Electromagnetic fields (EMF)	9
Warranty and support	9
Introduction	11
General description	12
Description of functions	14
Before first use	15
Preparations before first use	16
Cooking instruction	17
Cooking in dual pan	17
Cooking in single pan	22
Cleaning	48
Use automated cleaning programs	48
General cleaning	58
Accessories	60
Storage	65
Troubleshooting	65

Important safety instruction

Read this important information carefully before you use the appliance and save it for future reference.



Danger

- Do not place the appliance on or near a hot gas stove or all kinds of electric stove and electric cooking plates, or in a heated oven.
- Never immerse the appliance in water nor rinse it under the tap.
- Do not let any water or other liquid enter the appliance to prevent electric shock.
- Always put the ingredients to be fried in the basket, to prevent them from coming into contact with the heating elements.
- Do not cover the air inlet and the air outlet openings while the appliance is operating.
- Do not fill the pan with oil as this may cause a fire hazard.
- Do not use the appliance, if the plug, the mains cord or the appliance itself is damaged.
- Never touch the inside of the appliance while it is operating.
- Always make sure heater is free and no food stuck in heater.
- Before first use, the cord storage must be assembled onto the device. Do not remove the cord storage at any time.

Warning

- If the supply cord is damaged, it must be replaced by Philips, its service agent or similarly qualified persons in order to avoid a hazard.
- Only connect the appliance to an earthed wall socket, protected by an earth leakage circuit breaker.
- Always make sure that the plug is inserted into the wall socket properly.
- This appliance is not intended to be operated by means of an external timer or a separate remotecontrol system.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Keep the appliance and its cord out of reach of children less than 8 years.
- Do not place the appliance against a wall or against other appliances. Leave at least 15 cm free space at the back, on both sides and above the appliance. Do not place anything on top of the appliance.
- During hot air frying, hot steam is released through the air outlet openings. Keep your hands and face at a safe distance from the steam and from the air outlet openings. Also, be careful of hot steam and air when you remove the pan from the appliance.
- Never use light ingredients or baking paper in the appliance.


- Accessible surfaces may become hot during use.
- Storage of potatoes: The temperature shall be appropriate to the potato variety stored and it shall be above 6 °C to minimize the risk of acrylamide exposure in the prepared foodstuff.
- Never fill the pan with oil.
- Since this Airfryer has two cooking chambers, its electric power is large. Do not operate other powerful appliances on the same circuit at the same time (e.g., kettles, electric grills, and the like). Else, it can happen that the circuit breaker in your house installation responds and the power at this socket fails.
- This appliance is designed to be used at ambient temperatures between 5°C and 40°C.
- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- Keep the mains cord away from hot surfaces.
- Do not place the appliance on or near combustible materials such as a tablecloth or curtain.
- Do not use the appliance for any other purpose than described in this manual and use only original Philips accessories.
- Do not let the appliance operate unattended.
- The pan, basket, and accessories placed inside the cooking chamber becomes hot during and after use of the appliance, always handle carefully.
- Thoroughly clean the parts that come into contact with food before you use the appliance for the first time. Refer to the instructions in the manual.
- When steaming food, be careful when opening the lid to avoid burns from rushing steam.
- The idle compartment is always hot even if the another one is in operation.
- Unused appliance compartment / cavity can become hot when the other compartment / cavity is in use and that it is advised to keep all drawers in place even when a single compartment / cavity is in use, and only to open / remove when this is needed for filling of the drawer.
- Don't place the appliance steam window against the socket.



Caution

- This appliance is intended for normal household use only. It is not intended for use in environments such as staff kitchens of shops, offices, farms or other work environments. Nor is it intended to be used by clients in hotels, motels, bed and breakfasts and other residential environments.
- Always disconnect the appliance from the supply if it is left unattended and before you assemble, disassemble, store or cleaning.
- Place the appliance on a horizontal, even and stable surface.
- If the appliance is used improperly or for professional or semi-professional purposes or if it is not used according to the instructions in the user manual, the guarantee becomes invalid and Philips refuses any liability for damage caused.
- Always return the appliance to a service center authorised by Philips for examination or repair. Do not attempt to repair the appliance yourself, otherwise the guarantee becomes invalid.
- Do not unplug the device right after the cooking process is finished.
- Let the appliance cool down for approximately 30 minutes before you handle or clean it.

- Make sure the ingredients prepared in this appliance come out golden yellow instead of dark or brown.
- Remove burnt remnants. Do not fry fresh potatoes at a temperature above 180°C (to minimise the production of acrylamide).
- Be careful when cleaning the upper area of the cooking chamber: Hot heating element, edge of metal parts, and splatter shield.
- Always make sure that the food is fully cooked in the Airfryer.
- Be cautious when cooking easy perishable food with the sync finish function (bacteria may breed).
- Be careful when pouring out the cooked food and be careful not to let the accessories fall out.
- The cord holder also serves as a spacer, by creating distance between the device and the wall to prevent heat accumulation. Never remove this spacer.
- When the descaling icon lights up, proceed with the descaling process.
- Place the device 20 cm away from the wall, and do not position the air outlet directly in front of the socket. Do not place the Airfryer next to another cooking appliance, close to the kitchen wall, or beneath a kitchen cupboard, as hot steam may condense and run down the surfaces.
- In normal use, good ventilation must be ensured around the product.
- If steam accumulates inside or around the surface of the steam vent, wipe with a soft dry cloth.
- If there are condensation water on vacant socket, it is recommended to adjust the position of the device or use the socket dust cover to avoid condensation accumulated in vacant sockets.



Recycling



- This symbol means that electrical products shall not be disposed of with normal household waste.
- Follow your country's rules for the separate collection of electrical products.



Electromagnetic fields (EMF)

This appliance complies with the applicable standards and regulations regarding exposure to electromagnetic fields.

Warranty and support

Versuni Netherlands B.V., registered at Claude Debussylaan 88, Amsterdam, NL, offers a two-year warranty on this product after the date of purchase (or the

date of delivery, if later). This warranty is not valid if a defect is due to incorrect use or poor maintenance. Our warranty does not affect your rights under law as a consumer. For more information, for spare parts, or for invoking the warranty, please visit our website **home.id/warranty**.

Introduction

Congratulations and welcome to the Philips Family!

To fully benefit from the support that we offer, register your product at **www.philips.com/welcome**.


The dual baskets Airfryer with steam allows you to prepare two ingredients with separate cooking methods, both ready at the same time. Two baskets for frying, baking, roasting, and grilling, with the big one also equipped for steaming. Enjoy perfectly cooked meals with RapidAir Plus and Air Steam Technology.

Additionally, this airfryer is equipped with auto cleaning program such as steam cleaning and descaling. Steam clean can make it easier to remove fat building up from the big pan and around the heating tube. Descaling function helps clean limescale buildup in the device's water system and extends its lifespan.

It comes with the Home ID app that gives you step by step guidance and hundreds of mouthwatering meals with specific settings for your Dual Basket Airfryer.

Download the app by using the QR code on the pack.


General description



Main parts

1	Water tank lid	8	Bottom plate for small pan
2	MAX water level indication	9	Cord holder
3	Water tank	10	Power cord
4	Control panel	11	Air Outlets
5	Basket for big pan	12	Breakfast kit (NA55X/03 only)
6	Big pan	13	Double layer with skewers (NA55X/04 only)
7	Small pan		

Control panel



- a On/Off button
- b Time function
- c Back button
- d Start/pause button

Small pan control buttons

- e Small pan button
- f Shaking reminder button
- g Temperature control buttons
- h Time control buttons

Big pan control buttons

- i Big pan button
- j Shaking reminder button
- k Airfry function button
- l Steam&airfry function button
- m Steam function button
- n Steam clean function button
- o Temperature control buttons
- p Time control buttons
- q Preset buttons
- r No water indication
- s Descaling reminder icon

Description of functions



Water tank

The air fryer has a water tank located at the top of the appliance. The MAX water level indication is about 800 ml, visible from both the front and back. To prevent water leakage, do not exceed this level.

To avoid spills, hold the water tank with both hands while filling it, and close the lid before moving it. Empty the water tank after each cooking cycle to prevent limestone buildup.



Time function

Automatically syncs the cook time to ensure both pans finish cooking at the same time, even if there are different cook times.



Back Button

Use the back button if you mistakenly chose the wrong preset/function.



Shaking reminder

Press the shaking reminder button to enable or disable alerts that remind you to shake or turn your food twice during cooking for more even results. You'll hear a "beep" and see a shaking icon 🌀 flashing beside the time display.



Airfry function

RapidAir Plus Technology with a unique star-shaped design circulates hot air around and through the food, ensuring even cooking inside and out for delicious homemade meals.



Steam&airfry function

For big pan only: Achieve the tenderness of steaming with the crispiness of air frying using RapidAir Plus with Air Steam Technology.



Steam function

For big pan only: Our Air Steam Technology ensures a good infusion of steam for your veggies, fish, dumplings, or baked goods, achieving a tender and delicate texture without being soggy or watery.



No water indication icon

It is the icon on the right digit display. When it flashes with a "beep" sound, it indicates that there is no water in the tank or that the tank is not placed properly. Fill the tank with water and ensure it is in place; then press Stop/Start button and the sign will turn off.



Steam clean function

For big pan only: Press the Steam clean button once to start cleaning the right chamber and help dissolve greasy residues in the pan and around the heater. See Chapter "Cleaning- Steam cleaning" for details.



Descaling function

For big pan only: Long press the steam clean button  for at least 3 seconds until the descaling icon flashes. See Chapter "Cleaning-Descaling" for details.



Pause cooking

Press the Start/pause button or re-insert the "pan/basket" to resume cooking.

Presets

Presets below are cooking programs that give recommendation for temperature and cooking time based on a certain amount of food. For further details see chapter "Cooking with Presets".



Frozen potato
based snacks



Steak



Fresh potatoes



Vegan



Chicken
drumsticks



Fish



Vegetables



Bread



Muffin/
Cake



Reheat



Dumplings

Appliance noise

You might hear some noise while the appliance works. This is normal and comes from the pump and fan.


Sound notifications

Sometimes you hear a sound, for example when the appliance has finished cooking, or when there is an action required during cooking, e.g., shaking or turning food.

Before first use

Important


- **During the first time use, the airfryer may produce some smoke and smell. This should dissipate in a few minutes.**
 - **Before first time of cooking, please follow chapter "Cleaning" to clean device thoroughly.**
- 1 Remove all packing material.
 - 2 Remove any stickers or labels (if applicable) from the appliance.
 - 3 Thoroughly clean the appliance before first use (see chapter "cleaning").



- 4 Attach the cord holder to the designated area on the back of the device by clicking it into place.

Caution

- The cord holder also serves as a spacer, by creating distance between the device and the wall to prevent heat accumulation.




Caution

- This is an Air Fryer that works on hot air. Do not fill the pan with oil, frying fat, or any other liquid.
- Do not touch hot surfaces. Handle the hot pan with oven-safe gloves.
- This appliance is for household use only.
- This appliance may produce some smoke when you use it for the first time. This is normal.
- Preheating of the appliance is not necessary.


Preparations before first use

Place the appliance on a stable, horizontal, level and heat-resistant surface.

Note



- Do not put anything on top or on the sides of the appliance. This could disrupt the airflow and affect the frying result.
- Do not place the Airfryer next to another cooking appliance, close to the kitchen wall, or beneath a kitchen cupboard, as hot steam may condense and run down the surfaces.
- In normal use, good ventilation must be ensured around the product.



- During use, hot steam is released through the air outlet. Keep your hands and face safely away from the steam and outlet. Place the device 20 cm away from the wall, and do not position the air outlet directly in front of the socket.

Cooking instruction

There are different cooking functions for the left and right pans. You can choose the corresponding pan for the desired cooking function.

Cooking mode

	Air fry	Steam&airfry	Steam
			
Small pan 	✓	✗	✗
Big pan 	✓	✓	✓

Before using the steam or steam & airfry function, make sure there is enough water in the tank.

Note: If you live in an area with hard water, we recommend using purified water or distilled water.

Do not exceed the MAX water level indication on the water tank.


Empty the water tank after cooking.


Cooking in dual pan

Cooking with time function


If cooking two foods with different functions, temperatures, and time, use the **Time function** to finish both pans at the same time.

1 Put the plug in the wall outlet.






- 2 Remove both pans from the appliance by pulling the handle.



- 3 Put the bottom plate into the small pan.



- 4 Put the basket into big pan.

Note


- Make sure the basket's flaps are correctly positioned on the right and left sides when inserting it into the pan. If you accidentally rotate it 90 degrees, the basket will not fit.
- It's normal to apply some force to place the basket in the pan.

- 5 Put the ingredients in the baskets.


- 6 Put the pans back into the Airfryer.


Caution

- **Do not touch the pan or the basket during and for some time after use, as they get very hot.**




- 7 Press the Power On/Off button to switch on the appliance.






8 Select the small pan.


The time and temperature indication on the left side starts blinking.



9 Press the temperature up/down button and time up/down button to choose the needed time and temperature.




10 Select the big pan.



11 Select the desired cooking function: air fry, steam, or steam&airfry function.


Before selecting the steam or steam&airfry function, fill the water tank to the MAX level indication.




12 Press the temperature up/down button and time up/down button to choose the needed time and temperature.

If you choose the air fry or steam&airfry function, you can adjust the cooking temperature. For the steam function, the temperature is fixed at 100°C and is not adjustable.

Refer to the food table in Chapter "Cooking in single pan" for suggested food amounts, temperatures, and cooking time.




- 13** Press the Shaking reminder button to be reminded to shake your food during cooking process.




- 14** Press the Time function button to ensure both dishes finish cooking at the same time.

If you're cooking two foods with different functions, temperatures, and cooking times, and they don't need to finish at the same time, you can skip this step.


While cooking, if you adjust the time for one pan, the **Time function** will be disabled, and both pans will operate separately. To activate the **Time function** again, press the Start/Pause button. Then, press the **Time function** button that appears. Finally, press the Start/Pause button again to resume cooking.




- 15** Press the Start/Pause button to start the cooking process.




- 16** When you hear the sound signal of the shaking reminder, remove the pan with the basket and shake it over the sink. Then, place the pan back into the appliance.





17 When you hear the timer bell, the cooking time has elapsed.



18 Pull out the pans and check if the ingredients are ready.

If not done yet, just slide the pan back into the Airfryer and add a few more minutes.

19 Carefully remove the ingredients (e.g. fries) from the pan with barbecue tongs.

Note

- To pause both pans, press the Start/Pause button. Press it again to continue cooking for both pans.
- To pause only one pan, select that pan first, then press the Start/Pause button. Press it again to continue cooking for that pan.
- You can use a preset in one pan and manual settings in the other.
- The device automatically pauses when you pull out a pan and resumes cooking when you put it back in.

For instructions on different cooking functions, refer to the corresponding sections in Chapter "Cooking in single pan".

Cooking in single pan

If you want to air fry a small food portion, select the small pan .

If you want to air fry, steam&airfry, or steam a large food portion, select the big pan .

The instructions below are for the big pan.


Note

- To remove large or delicate ingredients, use tongs to lift them out.
- Depending on the ingredients, you may want to carefully pour off excess oil or fat from the pan after each batch or before shaking or replacing the basket. Place the basket on a heat-resistant surface and wear oven-safe gloves when pouring off excess oil or fat. Then, return the basket to the pan.


Air fry function

Air fry in big pan with the food table


- 1 Put the plug in the wall outlet.



- 2 Remove the big pan with the basket from the appliance by pulling the handle.




- 3 Put the basket into the big pan.
- 4 Put the ingredients in the basket.



Note


- The Airfryer can prepare a large range of ingredients. Consult the "Food table" for the right quantities and approximate cooking times.
- Do not exceed the amount indicated in the 'Food table' section or overfill the basket as this could affect the quality of the end result.




- 5 Put the pan back into the Airfryer.

Caution


- Do not touch the pan or the basket during and for some time after use, as they get very hot.




- 6 Press the Power On/Off button to switch on the appliance.




- 7 Select the big pan.




- 8 Select the Airfry function button.
The time and temperature indication on the right side starts blinking.



- 9 Press the temperature up/down button and time up/down button to choose the needed time and temperature (see "Food table").




- 10** Press the Shaking reminder button to be reminded to shake your food during cooking process if ingredients require shaking or turning (see "Food table").





- 11** Press the Start/Pause button to start the cooking process.
The temperature and time display stop blinking.

Note


- The last cooking minute counts down in seconds.
- You can change the cooking settings at any time during the cooking process by clicking the up or down buttons.



- 12** When you hear the sound signal of the shaking reminder , pull out the pan with the basket and shake it over the sink. Then, put the pan back into the appliance.



- 13** When you hear the timer bell, the cooking time has elapsed.



14 Pull out the pan and check if the ingredients are ready.


Caution

- **The Airfryer pan is hot after the cooking process. Always place it on a heat resistant work top (eg. trivet, etc.) when you remove the pan from the device.**

Note

- If the ingredients are not ready yet, simply slide the pan back into the Airfryer and add a few extra minutes.

15 Carefully remove the ingredients (e.g. fries) from the pan with barbecue tongs.



Caution

- **Do not tilt the pan when removing the ingredients as the basket could fall out of the pan.**
- **After the cooking process, the pan, the basket, the interior housing and the ingredients are hot. Depending on the type of ingredients in the Airfryer, steam may escape from the pan.**

Food table - big pan

The cooking time in the table are guidelines for fresh ingredients. If the results are not as expected, adjust the cooking time.



Ingredients	Food amount	Temperature	Time (min)	Note
Thin frozen fries (7x7 mm/0.3x0.3 in)	800 g / 28 oz	200 °C	28-31	- 7x7 mm / 0.3x0.3 in thick - Shake, turn or stir 2 times in between
Thin frozen fries (7x7 mm/0.3x0.3 in) Big portion	900 g / 32 oz	200	29	- Turn off the shaking reminder and manually shake or turn the food promptly at 14, 18, 21, and 25 minutes. - Shake 4 times during the cooking process to achieve optimal cooking performance for big portions of fries.

Homemade fries	800 g / 28 oz	180°C	30-40	- 10x10 mm / 0.4x0.4 in thick - Shake, turn or stir 2 times in between
Frozen chicken nuggets	600 g/ 21 oz	200°C	10-20	- Shake, turn or stir halfway
Frozen spring rolls	600 g/ 21 oz	200°C	18-24	- Shake, turn or stir halfway
Hamburger	4 patties	200 °C	15-20	- Around 150 g/5 oz/piece - Turn halfway
Meat loaf	1200 g / 42 oz	150°C	55-60	- Use the baking accessory
Meat chops without bone	4 chops	200°C	15-20	- Around 150 g/5 oz - Shake, turn or stir halfway
Thin sausages	10 pieces	200°C	11-15	- Around 50 g/1.8 oz/piece - Shake, turn or stir halfway
Chicken drumsticks (around 125 g/4 oz/piece)	4 pieces	180°C	23	- Shake, turn or stir halfway
Chicken breast	4 pieces	180°C	15-25	- Around 200 g/7oz/piece - Turn halfway
Whole chicken	1200 g/42 oz	180°C	50-60	
Whole fish	3 pieces	180°C	20-25	- Around 300-400 g/11-14 oz/piece
Fish filet	5 pieces	160°C	25-32	- Around 200 g/7 oz

Mixed vegetables	1000 g/35 oz	180°C	22	-	Turn off the shaking reminder and manually shake or stir the food promptly at 11 and 17 minutes during the cooking process to achieve optimal cooking performance for big portions of mixed vegetables.
Muffins (around 40 g/piece)	6 pieces	160°C	13		
Cake	500 g/18 oz	150°C	35-40	-	Use the XL cooking and baking pot Check the doneness before you take out the cake
Pre-baked bread/rolls (around 60g/2.1 oz)	4 pieces	180°C	8		

Vegan	12 pieces	180°C	12-15	- Fresh convenience vegan snacks such as falafel - Shake, turn or stir 2-3 times in between
Homemade bread	550 g / 19 oz	150°C	33-35	- Use the XL cooking and baking pot - The shape of the dough should be as flat as possible to avoid that the bread touches the heating element when rising - Check the doneness before you take the bread



Food table - small pan

The cooking time in the table are guidelines for fresh ingredients. If the results are not as expected, adjust the cooking time.


Ingredients	Food amount	Temperature	Time (min)	Note
Thin frozen fries	300 g / 11 oz	200°C	28-30	- 7x7 mm / 0.3x0.3 in thick - Shake, turn or stir 2-3 times in between
Thin frozen fries (7x7 mm/0.3x0.3 in) Big portion	670 g/24 oz	200	48	- Turn off the shaking reminder and manually shake or turn the food promptly at 21, 27, 34, and 40 minutes. - Shake 4 times during the cooking process to achieve optimal cooking performance for big portions of fries.
Homemade fries	300 g / 11 oz	180°C	30-38	- 10x10 mm / 0.4x0.4 in thick - Shake, turn or stir 2-3 times in between
Frozen chicken nuggets	300 g / 11 oz	200°C	20-22	- Shake, turn or stir halfway
Frozen spring rolls	300 g / 11 oz	200°C	20-23	- Shake, turn or stir halfway
Hamburger	300g / 11 oz	200 °C	21-24	- Around 150 g/5 oz/piece - Turn halfway
Meat chops without bone	300g / 11oz	200°C	20-22	- Around 150 g/5 oz/piece - Shake, turn or stir halfway

30 English

Thin sausages	6 pieces	200°C	13-17	- Around 50 g/1.8 oz/piece - Shake, turn or stir halfway
Chicken drumsticks (around 125 g/4 oz/piece)	4 pieces	180°C	29	- Shake, turn or stir halfway
Chicken breast	3 pieces	180°C	20-25	- Around 200 g/7oz/piece - Turn halfway
Whole fish	1 piece	180°C	24-26	- Around 300-400 g/11-14 oz/piece
Fish filet	2 pieces	160°C	25-32	- Around 200 g/7 oz/piece
Mixed vegetables (roughly chopped)	800 g/28 oz	180	24	- Turn off the shaking reminder and manually shake or stir the food promptly at 12 and 18 minutes during the cooking process to achieve optimal cooking performance for big portions of mixed vegetables.
Muffins (around 40 g/piece)	5 pieces	160°C	18	
Pre-baked bread/rolls (around 60 g/2.1 oz)	3 pieces	180	8	
Vegan	12 pieces	190°C	15-18	- Fresh convenience vegan snacks such as falafel - Shake, turn or stir 2-3 times in between

Airfry with a preset in big pan


1 Follow steps 1 to 8 in chapter "Air fry in big pan with food table.



2 Choose the preset.

Tip:

- To change to another preset, press the back button or deselect the preset button and select your needed preset.



3 Start the cooking process by pressing the Start/Pause button.

The temperature and time indication stop blinking.

Refer to the table below for suggested food amounts based on the default cooking time.



Preset - Big pan

The cooking time in the table are guidelines for fresh ingredients. If the results are not as expected, adjust the cooking time.

Presets	Icon	Food amount	Temperature (default)	Time (default)	Note
Frozen potato based snacks		800g / 28 oz	200 °C	28 min	- Potato based frozen snacks like frozen French fries, potato wedges, criss-cross fries etc. Shake, turn or stir 2-3 times in between
Steak (aka beef and pork chops)		600g / 21 oz	200 °C	20 min	- Slices with 2-2,5 cm thickness, 200g / 7 oz each slice. - Up to 4 meat chops without bone. - Turn once
Vegan (aka fresh convenience vegan snacks such as falafel)		12 pieces	180 °C	12 min	- 40g for each piece - A fresh convenience vegan snacks such as falafel - Shake, turn or stir 2-3 times in between.
Fresh potatoes (aka roasted potatoes)		800g / 28 oz	180 °C	30 min	- Use mealy potatoes - 10x10mm / 0.4x0.4 in thick cut - Soak 30 minutes in water, dry then add ¼ to 1 tbsp of oil. - Shake, turn or stir 2-3 times in between.
Chicken drumsticks (aka poultry)		8 - 10 Stk	180 °C	32 min	- 120-130g / 4-5 oz for each drumstick - Shake, turn or stir in between.
Fish (aka fish and seafood)		600g / 21 oz	180 °C	23 min	- Whole fish with skin around 300 g / 11 oz
Vegetables		1000g / 35 oz	180 °C	22 min	- Roughly chopped - Mixed vegetables (aubergine, courgette, pepper, onion)
Cake		500 g / 18 oz	140 °C	35 min	- Use the XL baking accessory (199 x 189 x 80 mm) for big pan.

Presets	Icon	Food amount	Temperature (default)	Time (default)	Note
Bread		500g / 17 oz	180 °C	35 min	- Use the XL cooking and baking pot. - The shape of the dough should be as flat as possible to avoid that the bread touches the heating element when rising. - Check the doneness before you take out the bread.
Reheat		-	160 °C	5 min	- Adjust time according to food item and food amount



Preset - Small pan

The cooking time in the table are guidelines for fresh ingredients. If the results are not as expected, adjust the cooking time.

Presets	Icon	Food amount	Temperature (default)	Time (default)	Note
Frozen potato based snacks		300g / 11 oz	200 °C	30 min	- Potato based frozen snacks like frozen French fries, potato wedges, criss-cross fries etc. Shake, turn or stir 2-3 times in between
Steak (aka beef and pork chops)		400 g / 14 oz	200 °C	22 min	- Slices with 2-2,5 cm thickness, 200g / 7 oz each slice. - Up to 4 meat chops without bone. - Turn once
Vegan (aka fresh convenience vegan snacks such as falafel)		8 pics	190 °C	15 min	- 40g for each piece A fresh convenience vegan snacks such as falafel Shake, turn or stir 2-3 times in between
Fresh potatoes (aka roasted potatoes)		300g / 11 oz	180 °C	35 min	- Use mealy potatoes - 10x10mm / 0.4x0.4 in thick cut - Soak 30 minutes in water, dry then add ¼ to 1 tbsp of oil. - Shake, turn or stir 2-3 times in between..
Chicken drumsticks (aka poultry)		4-5stk	180 °C	36 min	- 120-130g / 4-5 oz for each drumstick - Shake, turn or stir in between

Presets	Icon	Food amount	Temperature (default)	Time (default)	Note
Fish (aka fish and seafood)		300g / 11 oz	180 °C	25 min	- Whole fish with skin around 300 g / 11 oz
Vegetables		400g / 14 oz	180 °C	25 min	- Roughly chopped - Mixed vegetables (aubergine, courgette, pepper, onion)
Muffin		6 pics	150 °C	20 min	- Use muffin cups for small basket
Bread		300g / 11 oz	160 °C	40 min	- Use baking accessory
Reheat		-	170 °C	6 min	- Adjust time according to food item and food amount

Tip: Keep Warm

- You can keep your food warm in the Airfryer by setting the temperature to 80 degrees and adapt the time as long as you want to keep your food warm. We recommend not to keep your food warm for more than 30 minutes as the quality of the food can decrease.
- If food like French fries loses too much crispness during the keep warm mode, either shorten the keep warm time by switching off the appliance earlier or crisp them up for 2-3 minutes at the temperature of 180°C.

Making home-made fries

To make great home-made fries in the Airfryer:

- For the big pan you need 800 g / 28 oz and for the small pan 300 g / 11 oz of peeled potatoes.
 - Choose a potato variety suitable for making fries, e.g. fresh, (slightly) floury potatoes.
 - It is best to air fry the fries in portions of up to 800 g / 28 oz for an even result. Larger quantities of fries tend to be less crispy than smaller portions.
- 1 Peel the potatoes and cut into fries (10x10 mm / 0.4x0.4 in thick).
 - 2 Soak the potato sticks in a bowl of water for at least 30 minutes.
 - 3 Empty the bowl and dry the potato sticks with a dish towel or paper towel.
 - 4 Pour one tablespoon of cooking oil into the bowl, put the sticks in the bowl and mix until the sticks are coated with oil.
 - 5 Remove the sticks from the bowl with your fingers or a slotted kitchen utensil so excess oil remains in the bowl.


Note

- Do not tilt the bowl to pour all the sticks in the basket at once to prevent excess oil from going into the pan.
- 6 Put the sticks into the basket.

Steam&airfry function


Steam&airfry with food table

- 1 Remove the water tank from the appliance.




- 2 Fill the water tank with water up to the **MAX** water level.

Note: If you live in an area with hard water, we recommend using purified water or distilled water.




- 3 Secure the lid on the water tank to avoid water leakage.





- 4 Place the water tank onto the groove at the top of the appliance and press down to ensure it is secured.

If the water tank is not placed properly, water won't flow to the steam generator. This will cause the "no water" icon  to flash and may produce strange noises from the fan and motor. The steam&airfry function might be disabled in this case.




- 5 Put the plug in the wall outlet.






- 6** Remove the big pan with the basket from the appliance by pulling the handle.



- 7** Put the basket into the big pan.
8 Put the ingredients in the basket.

Note


- The Airfryer can prepare a large range of ingredients. Consult the 'Food table' for the right quantities and approximate cooking times.
- Do not exceed the amount indicated in the 'Food table' section or overfill the basket as this could affect the quality of the end result.




- 9** Put the pan back into the Airfryer.

Caution

- **Do not touch the pan or the basket during and for some time after use, as they get very hot.**



- 10** Press the Power On/Off button to switch on the appliance.




- 11** Select the big pan.




12 Select steam&airfry function.


The time and temperature indication on the right side starts blinking.



13 Press the temperature up/down button and time up/down button to choose the needed time and temperature (See to the food table as below).



14 Press the Shaking reminder button to be reminded to shake your food during cooking process if needed.




15 Press the Start/Pause button to start the cooking process.



The temperature and time indication stop blinking.

Note


- The last cooking minute counts down in seconds.
- If the temperature and time on the display are steady and not blinking, it means the appliance is working normally. After 20 seconds of cooking, you'll hear the motor/fan and see steam coming from the back of the machine.
- You can change the cooking settings at any time during the cooking process by clicking the up or down buttons.

16 When you hear the sound signal of the shaking reminder, pull out the pan with the basket and shake it over the sink. Then, put the pan back into the appliance.





17 When you hear the timer bell, the cooking time has elapsed.



18 Pull out the pan and check if the ingredients are ready.

Caution

- **The Airfryer pan is hot after the cooking process. Always place it on a heat resistant work top (eg. trivet, etc.) when you remove the pan from the device.**


Note

- If the ingredients are not ready yet, simply slide the pan back into the Airfryer and add a few extra minutes.

19 Carefully remove the ingredients from the pan with barbecue tongs.

Caution

- **Do not tilt the pan when removing the ingredients, as the basket could fall out and water may splash.**
- **After the cooking process, the pan, the basket, the interior housing and the ingredients are hot. Depending on the type of ingredients in the Airfryer, steam may escape from the pan.**





Food table - big pan

Ingredients	Food amount	Temperature	Time (min)	Note
Fresh potato cubes (aka roasted potatoes)	800g/ 28 oz	180 °C	26-35	- Shake, turn or stir 2 times in between
Chicken drumsticks	10 pieces	180 °C	27-30	- Around 125g /4 oz/piece - Shake, turn or stir halfway
Chicken breast	4 pieces	160 °C	20-22	- Around 200 g/7oz/piece - Add 10 g canola oil
Whole fish	3 pieces	200 °C	18-21	- Around 300-400 g/11-14 oz/piece - Shake, turn or stir halfway
Fish filet	5 pieces	160 °C	20-21	- Around 200 g/7 oz - Add 10 g canola oil
Mix Vegetables	1000 g/35 oz	200 °C	19-21	- Set the cooking time according to your own taste - Shake, turn or stir 2 times in between
Cauliflower	600 g / 21 oz	160 °C	19-21	- Shake, turn or stir 2 times in between - 10 g canola oil
Carrots	600 g / 21 oz	180 °C	19-21	- Shake, turn or stir 2 times in between - 10 g canola oil

Homemade bread	550 g / 19 oz	180 °C	30-35	- Use the XL cooking and baking pot - The shape of the dough should be as flat as possible to avoid that the bread touches the heating element when rising - Check the doneness before you take the bread
----------------	---------------	--------	-------	---



Dumplings	400g/14 oz	160 °C	15-18
Whole chicken	1200 g/42 oz	180 °C	50-60

Steam&airfry with preset

- 1 Follow steps 1 to 12 in chapter "Steam&airfry function - Steam&airfry with food table".
- 2 Choose the preset.

Tip

- To change to another preset , press the back button or deselect the preset button and select your needed preset.



- 3 Start the cooking process by pressing the Start/Pause button. The temperature and time indication stop blinking.



Preset table


The cooking time in the table are guidelines for fresh ingredients. If the results are not as expected, adjust the cooking time.

Presets	Icon	Food amount	Temperature (default)	Time (default)	Note
Fresh potatoes(aka roasted potatoes)		800g / 28 oz	180 °C	26 min	- Use mealy potatoes - 10x10mm / 0.4x0.4 in thick cut - Soak 30 minutes in water, dry then add ¼ to 1 tbsp of oil - Shake, turn or stir 2-3 times in between
Chicken drumsticks (aka poultry)		8 - 10 Stk	180 °C	27 min	- 120-130g / 4-5 oz for each drumstick - Shake, turn or stir in between
Fish (aka fish and seafood)		600g / 21 oz	200 °C	18 min	- Whole fish with skin around 300 g / 11 oz
Vegetables		550g / 19 oz	160°C	19 min	- Hard vegetables,like broccoli/cauliflower - The shaking reminder is enabled by default and prompts you to shake the pan twice during cooking. - If you cook mixed vegetables (aubergine, courgette, pepper, onion),pls adjust temperature to 200°C
Bread		500g / 17 oz	180 °C	30 min	- Use the XL cooking and baking pot - The shape of the dough should be as flat as possible to avoid that the bread touches the heating element when rising - Check the doneness before you take out the bread
Dumplings		400g / 14 oz	160 °C	15 min	-
Reheat		-	150 °C	20 min	- Adjust time according to food item and food amount

Steam function

Steam with food table

- 1 Remove the water tank from the appliance.




- 2 Fill the water tank with water up to the **MAX** water level.


Note: If you live in an area with hard water, we recommend using purified water or distilled water.

The amount of water needed for cooking depends on the food type and cooking duration.

You may need to refill the water tank during cooking if the cooking time is over 50 minutes.




- 3 Secure the lid on the water tank to avoid water leakage.





- 4 Place the water tank onto the groove at the top of the appliance and press down to ensure it is secured.

If the water tank is not placed properly, water won't flow to the steam generator. This will cause the "no water" icon  to flash and may produce strange noises from the fan and motor. The steam function might be disabled in this case.




- 5 Put the plug in the wall outlet.






- 6** Remove the big pan with the basket from the appliance by pulling the handle.



- 7** Put the basket into the big pan.
8 Put the ingredients in the basket.

Note


- The Airfryer can prepare a large range of ingredients. Consult the 'Food table' for the right quantities and approximate cooking times.
- Do not exceed the amount indicated in the 'Food table' section or overfill the basket as this could affect the quality of the end result.




- 9** Put the pan back into the Airfryer.

Caution

- **Do not touch the pan or the basket during and for some time after use, as they get very hot.**





- 10** Press the Power On/Off button to switch on the appliance.



- 11** Select the big pan.

**12** Select steam function.



The time on the right side starts blinking.

**13** Press the time up/down button to choose the needed time.**14** Press the Start/Pause button to start the cooking process.

The temperature and time indication stop blinking.

Note


- The last cooking minute counts down in seconds.
- If the temperature and time on the display are steady and not blinking, it means the appliance is working normally. After 20 seconds of cooking ,you'll hear the motor/fan and see steam coming from the back of the machine.
- You can change the cooking settings at any time during the cooking process by clicking the up or down buttons.

15 When you hear the timer bell, the cooking time has elapsed.**16** Pull out the pan and check if the ingredients are ready.**Caution**

- **The Airfryer pan is hot after the cooking process. Always place it on a heat resistant work top (eg. trivet, etc.) when you remove the pan from the device.**
- **Be careful of a sudden burst of hot steam when removing the basket after cooking.**

Note

- If the ingredients are not ready yet, simply slide the pan back into the Airfryer and add a few extra minutes.



17 Carefully remove the ingredients from the pan with barbecue tongs.

Caution

- Do not tilt the pan when removing the ingredients, as the basket could fall out and water may splash.
- After the cooking process, the pan, the basket, the interior housing and the ingredients are hot. Depending on the type of ingredients in the Airfryer, steam may escape from the pan.




Food table - big pan

Ingredients	Food amount	Temperature	Time (min)	Note
Fresh potato cubes	800g / 28 oz	100 °C	28-35	
Whole potato	4 pieces	100 °C	45-55	- Around 250-300g/9-11 oz/piece
Chicken drumsticks	10 pieces	100 °C	30-40	- Around 125g/4 oz/piece
Whole fish	3 pieces	100 °C	18-22	- Around 300-400 g/11-14 oz/piece
Hard vegetables	550g/19oz	100 °C	10-14	- Like broccoli, cauliflower
Dumplings	400g/14 oz	100 °C	15-20	
Pork ribs	300g/11 oz	100 °C	30-35	- Use plate of certain size
Rice	320g/11 oz	100 °C	25-30	- Using cooking pot, like baking pot, silicon tray etc. - Add 320 ml water in pot, rice/water ratio is 1:1.2
Chicken breast	4 pieces	100 °C	20-30	- Around 200g/7oz/piece
Yam/Sweet potato	8 pieces	100 °C	45-60	- Around 100g/4 oz/piece

Steam with preset


1 Follow steps 1 to 12 in chapter "Steam function".



2 Choose the preset.

Tip

- To change to another preset, press the back button or deselect the preset button and select your needed preset.



3 Start the cooking process by pressing the Start/Pause button.

The temperature and time indication stop blinking.



Preset table

The cooking time in the table are guidelines for fresh ingredients. If the results are not as expected, adjust the cooking time.

Presets	Icon	Food amount	Temperature (default)	Time (default)	Note
Fresh potatoes		800g / 28 oz	100 °C	35 min	- Cut into potato cubes
Chicken drumsticks (aka poultry)		8 - 10 Stk	100 °C	40 min	- 120-130g / 4-5 oz for each drumstick
Fish (aka fish and seafood)		600g / 21 oz	100 °C	20 min	- Whole fish with skin around 300 g / 11 oz
Vegetables		550g / 19 oz	100 °C	14 min	- Hard vegetables, like broccoli/cauliflower
Dumplings		400g / 14 oz	100 °C	20 min	-


Cleaning

Use automated cleaning programs

Using steam cleaning function


It helps dissolve greasy residue and deeply clean the big pan. The program lasts for 20 minutes, with 15 minutes for steam cleaning and 5 minutes for drying the pan.

- 1 Remove the water tank from the appliance.




- 2 Fill the water tank with water up to the **MAX** water level.

Note: If you live in an area with hard water, we recommend using purified water or distilled water.





- 3 Secure the lid on the water tank to avoid water leakage.




- 4 Place the water tank onto the groove at the top of the appliance and press down to ensure it is secured.

If the water tank is not placed properly, water won't flow to the steam generator. This will cause the "no water" icon  to flash and may produce strange noises from the fan and motor. The steam function might be disabled in this case.







- 5** Press the Power On/Off button to switch on the appliance




- 6** Select the big pan.



- 7** Press the Steam Clean button to start cleaning right chamber.
The time on the right side starts blinking.




- 8** Press the Start/Pause button to start cleaning process.
The temperature and time indication stop blinking.




- 9** After 15 minutes, the appliance will beep continuously and the steam clean icon ☁ will flash until you remove the pan.

This indicates that the cleaning process is complete and a drying phase of 5 minutes remains.



10 Remove and empty the pan.




11 Rinse the basket and pan to remove residue.


If grease remains in the pan and basket, clean them with soapy water or detergent using a sponge, then rinse again.

12 Wipe away any dissolved grease around the heater area with a mop or kitchen towel.

When using the air fry or steam&airfry functions, some grease will accumulate around the heater area. Regular steam cleaning and wiping will help keep the top interior clean.



13 Insert the pan back into the unit to start the dry mode automatically.



14 After 5 minutes, a beep sound indicates that the drying program is complete.

Tip

- Before first use or if not used for a long time, we suggest using the "Steam clean" function to thoroughly clean the water circle and right chamber.

Note

- When starting program of steam cleaning or descaling, it might generate more vapour than steam mode from the back of appliance, which indicates that more condensation you will see on the wall. Before starting these two programs, please ensure that 1) air outlet is not directly facing the socket; 2) do not place other kitchen appliances next to the machine; 3) Place the machine 20 cm away from the wall to reduce the formation of condensation on the wall.

Using descaling function

Every 10 hours of steam mode use, the icon ☺ will blink, indicating it's time to run a descale program. This function helps clean limescale buildup in the device's water system and extends its lifespan.

Depending on the software version of your appliance, there are two different ways for descaling.


- **(Method 1)** Water only method

- **(Method 2)** Water + descaler" method


Check the sticker on your appliance and compare it with the table below to select the correct descaling method for your appliance.

Note: For optimal descaling performance, follow the method indicated on the sticker on your product. If you have any questions, contact the service center hotline.

(Method 1) Use the "Water only" method when you see this sticker




(Method 2) Use the "Water + descaler" method when you see this sticker




(1) Water only method


1 Remove the water tank from the appliance.




2 Fill the water tank with water up to the **MAX** water level.

Note: If you live in an area with hard water, we recommend using purified water or distilled water.






- 3** Secure the lid on the water tank to avoid water leakage.




- 4** Place the water tank onto the groove at the top of the appliance and press down to ensure it is secured.

If the water tank is not placed properly, water won't flow to the steam generator. This will cause the "no water" icon  to flash and may produce strange noises from the fan and motor. The steam function might be disabled in this case.




- 5** Press the Power On/Off button to switch on the appliance




- 6** Select the big pan.




- 7** Long press the Steam Clean button for more than 3 seconds until the descaling icon  appears and blinks. The time on the right side starts blinking.




- 8** Press the Start/Pause button to begin descaling.
The time indication stop blinking.



- 9** Wait 50 minutes until you hear a beep, indicating the program has ended.



- 10** Remove the big pan.



- 11** Pour out the dirty water.


- 12** Wash the pan and basket, rinse and dry. Wipe the cooking chamber with dry cloth or kitchen towel.

Suggest to use the steam-clean function to rinse the inside water circle and dry the pan.


Note

- When the icon ☼ is flashing, it's best to descale promptly; otherwise, limescale might be accumulated in water circle and it will get clogged.
- If you want to descale later, you can skip the notification. You'll be reminded again the next time when you turn on your air fryer.
- Under no circumstances should you use a descaling liquid based on sulfuric acid, hydrochloric acid, sulfamic or acetic acid (vinegar) as this may damage the water system in your appliance and not dissolve the limescale properly.
- If you often use hard water in your area, you may need to descale the device more frequently.

(2) Water + Descaler method




- 1 Remove the water tank from the appliance.



- 2 Fill the water tank with 60 ml of Philips Descaler CA6700.


Note: Philips Descaler CA6700 is not included in the box. Purchase separately for best descaling results.

Note: To descale the appliance, we recommend using the Philips Descaler CA6700/55 (available from the Philips Online Shop). The appliance must be descaled after every 10 hours of steaming function usage. If you intend to use a descaler based on citric acid powder, we recommend mixing 40g of food-grade citric acid powder with 800ml of water for descaling solution. Failure to descale the appliance will void your warranty.




- 3 Fill the water tank with 740 ml of water.


Note: If you live in an area with hard water, we recommend using purified water or distilled water.



- 4 Mix the water and descaler evenly in the water tank.




- 5 Secure the lid on the water tank.




- 6** Place the water tank onto the groove at the top of the appliance and press down to ensure it is secured.

If the water tank is not placed properly, water won't flow to the steam generator. This will cause the "no water" icon  to flash and may produce strange noises from the fan and motor. The steam function might be disabled in this case.



- 7** Press the Power On/Off button to switch on the appliance




- 8** Select the big pan.




- 9** Long press the Steam Clean button for more than 3 seconds until the descaling icon  appears and blinks.

The time on the right side starts blinking.




- 10** Press the Start/Pause button to begin descaling.


The time indication stop blinking.



11 Wait 50 minutes until you hear a beep, indicating the program has ended.



12 Remove the big pan.




13 Pour out the dirty water.

Caution: Be careful when you handle the hot pan.




14 Pour off any remaining descaler solution in the water tank.




15 Refill the water tank with water only.


Note: If you live in an area with hard water, we recommend using purified water or distilled water.




- 16** Place the water tank onto the groove at the top of the appliance and press down to ensure it is secured.




- 17** Place the pan back to the appliance.



- 18** Press the **Start/pause** button to continue descaling.



- 19** The descaling process lasts for another 7 minutes and ends when you hear the appliance beep again.



- 20** Remove the big pan.

- 21** Wash the pan and basket, rinse and dry. Wipe the cooking chamber with dry cloth or kitchen towel.

Suggest to use the steam-clean function to rinse the inside water circle and dry the pan.

Note

- When the icon ☼ is flashing, it's best to descale promptly; otherwise, limescale might be accumulated in water circle and it will get clogged.
- If you want to descale later, you can skip the notification. You'll be reminded again the next time when you turn on your air fryer.

- Under no circumstances should you use a descaling liquid based on sulfuric acid, hydrochloric acid, sulfamic or acetic acid (vinegar) as this may damage the water system in your appliance and not dissolve the limescale properly.
- If you often use hard water in your area, you may need to descale the device more frequently.

General cleaning

Warning

- **Let the basket, pan and the inside of the appliance cool down completely before you start cleaning.**
- **The pan and basket of the appliance have a non-stick coating. Do not use metal kitchen utensils or abrasive cleaning materials as this may damage the non-stick coating.**



Clean the appliance after every use. Remove oil and fat from the bottom of the pan after every use.

If steam accumulates inside or around the surface of the steam vent, wipe with a soft dry cloth.

- 1 Press the power On/Off button to switch off the appliance, remove the plug from the wall outlet and let the appliance cool down.

Tip

- Remove the pan and basket to let the Airfryer cool down faster.




- 2 Dispose of rendered fat or oil from the bottom of the pan.
- 3 Clean the pan, basket in a dishwasher. You can also clean them with hot water, dishwashing liquid and a non-abrasive sponge (see "cleaning table").

Tip

- If food residues stuck to the pan or basket, you can soak them in hot water and dishwashing liquid for 10–15 minutes. Soaking loosens the food residues and makes it easier to remove. Make sure you use a dishwashing liquid that can dissolve oil and grease. If there are grease stains on the pan or basket and you have not been able to remove them with hot water and dishwashing liquid, use a liquid degreaser.
- If necessary, food residues stuck to the heating element can be removed with a soft to medium bristle brush. Do not use a steel wire brush or a hard bristle brush, as this might damage the coating on the heating element.



- 4 To prevent scratches, gently wipe the outside(including steam vent, surface etc..) and inside of the appliance with an unwrinkled, clean, and soft cloth. Begin with a slightly moistened cloth and follow up with a dry one, if necessary.



- 5 Clean the heating element with a cleaning brush to remove any food residues.



- 6 Clean the inside of the appliance with hot water and a non-abrasive sponge.





Note

- In case that you unintentionally pull out the divider, that is located between the small and the big pan, during cleaning, make sure to put it back in the right way.

Tip

- If food residues stick to the pan, use the automated cleaning program "Steam clean" to soften the residues and make cleaning easier (see "Use the automated cleaning programs").


Cleaning table

			
	✓	✓	✗
	✓	✗	✗
NA55X/03 	✓	✓	✓
NA55X/04 	✓	✓	✓

Accessories


Using the double layer


The double layer and skewer come with the following models: NA55X/03.



The double layer is a useful accessory that allows for cooking on two levels, but it is only compatible with the big pan.

- 1 Remove the big pan from the appliance.







2 Place the desired food into the basket.

Note


- Refer to the food table below for recommended items to cook with the double layer.



3 Place the double layer on top of the food in the basket.



4 Add the second portion of food onto the double layer.





5 Insert the pan into the appliance and adjust the time and temperature as specified in the following table. Once ready, press the start button.

Dishes	Weight (raw)	Cooking time	Temperature	Note
Frozen chicken nuggets	300 g / 11 oz	17–20 min	180°C	
Thin frozen fries	400 g / 14 oz			
Frozen chicken wings	450 g / 16 oz	16–20 min	200°C	
Frozen chicken burger patties	350 g / 12 oz			

Corncobs	800–1000 g / 28–35 oz	24–28 min	180°C	- 3 pieces of corncobs
Potato wedges	500 g / 18 oz			
Dorade	500–600 g / 18–21 oz	18–20 min	200°C	- 2 pieces of whole fish
Baked potato (quartered)	350 g / 12 oz			
Whole mushrooms	200 g / 7 oz			
King prawns with skin	400 g / 14 oz	12–14 min	200°C	
Grilled cheese or tofu	250 g / 9 oz	15–18 min	180°C	- Turn the grilled cheese or tofu halfway through the cooking time
Mixed vegetables	500 g / 18 oz			

Note

- The top food item listed in the table should be placed on the top level of the double layer and the second item on the bottom level.



- 1 After the cooking process is complete, use oven gloves and tongs to carefully remove the food from the basket.


Caution


- **Be cautious when removing the double layer as it becomes hot during cooking.**

Using the skewer


The skewer can be used in combination with the double layer.

- 1 Thread the desired meat and vegetables onto the skewers.






- 2 Place the skewers into the designated grooves on the double layer.



- 3 Put the pan back into the appliance.
4 Set the time and temperature according to the specified table and begin the cooking process.



- 5 Once cooking is complete, use oven gloves and tongs to carefully remove the food from the basket.

Refer to the table for specific recommendations on cooking times and temperatures.

Basket content	Portion	Cooking time	Temperature	Note
5 Skewers of food	5 skewers			- Put the mixed vegetables on the bottom of the pan, and the skewers on top of the double layer.
Mixed vegetables	500 g	15–18 min	180°C	

Using the breakfast kit


The breakfast kit comes with the following models: NA55X/04.




The breakfast kit allows for cooking up to four eggs and four pieces of toast simultaneously.

Caution

- To safely remove the cooked eggs and toast from the breakfast kit, always use tongs to prevent any potential risk of burning.




1 Remove the small pan from the appliance.




2 Take the bottom plate out of the pan.

Note

- If the bottom plate is not removed, the toast slices may not fit properly into the pan.




3 Place the breakfast kit into the small pan.



- 4 Place up to four eggs on the breakfast kit and insert the pan back into the appliance.
- 5 Adjust the time and temperature according to the food table below and press the start button.


Breakfast kit	Amount	Cooking time	Temperature	Note
Hard boiled eggs	4 eggs	10–12 min	180°C	- Cook the eggs first. Add the toast halfway through the cooking process.
Soft boiled eggs	4 eggs	8–10 min		
Toast	5 pieces	5–6 min		



- 1 Halfway through the cooking process, add the toast slices to the breakfast kit and continue cooking.

Tip

- Consider enabling the shaking reminder to avoid forgetting to add the toast.
- If the toast does not fit into the pan, cut it in half.



- 2 Once cooking is complete, use tongs to carefully remove the eggs and toast. Please refer to the food table below for specific cooking times and temperatures.

Storage

- 1 Unplug the appliance and let it cool down.
- 2 Make sure all parts are clean and dry before storing.
- 3 Wrap the cord around the designated cord holder on the backside of the appliance.

Note

- When carrying the Airfryer, always hold it horizontally to prevent the pans from accidentally falling out, which could potentially damage them.
- Always make sure that the removable parts of the Airfryer e.g. removable mesh bottom, etc. are fixed before you carry and/or store it.

Troubleshooting

This chapter summarizes the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, visit www.philips.com/support for a list of frequently asked questions or contact the Consumer Care Center in your country.

Problem	Possible cause	Solution
The outside of the appliance becomes hot during use.	The heat inside radiates to the outside walls.	This is normal. All handles and knobs that you need to touch during use stay cool enough to touch.

Problem	Possible cause	Solution
		The pan, the basket, and the inside of the appliance always become hot when the appliance is switched on to ensure the food is properly cooked. These parts are always too hot to touch.
		If you leave the appliance switched on for a longer time, some areas get too hot to touch. These areas are marked on the appliance with the following icon: 
		As long as you are aware of the hot areas and avoid touching them, the appliance is completely safe to use.
My home-made fries do not turn out as I expected.	You did not use the right potato type.	To get the best results, use fresh floury potatoes. If you need to store the potatoes, do not store them in a cold environment like in a fridge. Choose potatoes whose package states that they are suitable for frying.
	The amount of ingredients in the basket is too big.	Follow the instructions in this user manual to prepare home-made fries.
	Certain types of ingredients need to be shaken halfway through the cooking time.	Follow the instructions in this user manual to prepare home-made fries.
The Airfryer does not switch on.	The appliance is not plugged in.	Check if the plug is inserted in the wall outlet properly.
	Several appliances are connected to one outlet.	The Airfryer has a high wattage. Try a different outlet and check the fuses.
	On/Off button was not activated yet.	Use your thumb to press the On/Off button, ensuring the whole button is touched by finger.

Problem	Possible cause	Solution
I see some peeling off spots inside my Airfryer.	Some small spots can appear inside the pan of the Airfryer due to the incidental touching or scratching of the coating (e.g. during cleaning with harsh cleaning tools and/or while inserting the basket).	You can prevent damage by lowering the basket into the pan properly. If you insert the basket at an angle, its side may knock against the wall of the pan, causing small pieces of coating to chip off. If this occurs, please be informed that this is not harmful as all materials used are food-safe.
White smoke comes out of the appliance.	You are cooking fatty ingredients.	Carefully pour off any excess oil or fat from the pan and then continue cooking.
	The pan still contains greasy residues from previous use.	White smoke is caused by greasy residues heating up in the pan. Always clean the pan and the basket thoroughly after every use.
	Breading or coating did not adhere properly to the food.	Tiny pieces of airborne breading can cause white smoke. Firmly press breading or coating to food to ensure it sticks.
The screen on the Airfryer shows "E1".	Marinade, liquid or meat juices are splattering in the rendered fat or grease.	Pat food dry before placing it in the basket.
	The device is broken / has defects.	Call the Philips service hot line or contact the Consumer Care Center in your country.
The screen on the Airfryer shows "E4–E12".	Your Airfryer might be stored in a place where it is too cold.	If your device was stored at a low ambient temperature, let it warm up to room temperature for at least 15 minutes before you plug it in again. If your display still shows "E1", call the Philips service hot line or contact the Consumer Care Center in your country.
	The device might have a malfunction.	Try to plug out and plug in the device. If this does not help please call the Philips service hot line or contact the Consumer Care Center in your country.
I hear some strange noise coming from the inside of the appliance.	The appliance is equipped with a fan, which is needed to transport the heat to the food, and also a water pump, which is needed for the steaming function of the appliance.	This noise is normal and intended. If the noise gets louder or changes dearly, please contact the Philips support center for further advice.

Problem	Possible cause	Solution
There is water in the cooking chamber after cooking.	The Air fryer produces steam during cooking. The steam condenses on the food and on the inside walls of the cooking chamber. The condense water remains in the cooking chamber after cooking.	A certain amount of water remaining in the cooking chamber after cooking is normal. Just wipe it out with a wet, non-abrasive cloth.
 always flashes	No water in water tank	Add water in water tank.
	Water tank is not placed properly	Press down water tank in groove to secure it in place, and then press the Start/Pause button.
	Water tube blocked	Contact the consumer centre in your country and ask for further service.
 always flash	This is the reminder for descaling	Perform the descaling process. See chapter "Descaling".
There might be some condensation water on the wall during steaming, steam cleaning, descaling	It is normal, vapor will come out from air outlet of right side and pushed it to wall by fan	Place device 20cm away from wall and don't place right air outlet of device directly in front of the socket to avoid electrical problem. Do not put other kitchen appliances closed to it. Use mop to dry it.
The machine seems to be leaking	Leaking from inner part of device(leakage of water tube etc.)	Contact the consumer centre in your country and ask for further service.
	Device cracked by external force or deformation	
	Leakage from water tank	Take water tank out and install it properly again Check if there are any cracks in the water tank,contact consumer center in your country
Insufficient steam	Insufficient water in the water tank	Check the water tank to ensure there is enough water.
	The water tank is not fully inserted correctly	Press down water tank in groove to secure it in place, and then press the Start/Pause button.
	The water inlet in the groove on the top of the machine is dirty/clogged	Clean and rinse the water inlet.

Problem	Possible cause	Solution
	Clogging of the steam generator, or leakage of the steam pipeline	If it has been used for a long time, it may be necessary to perform descaling and cleaning of the steam generator. Start descaling program. If still not work, please contact consumer centre
There is no sound from fan or motor when starting program of steaming, steam & air frying, steam cleaning, descaling, but the indication of temperature and time are on and not blinking	It is normal. The appliance is working.	Wait more than 20 seconds to check the phenomenon again.
Condensation water on vacant socket during steaming, steam cleaning, descaling	Device placed too closely to the vacant sockets	It is recommended to adjust the position of the device or use the socket dust cover to avoid condensation accumulated in vacant sockets.

2026 © Versuni Holding B.V.

PHILIPS and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

This product has been manufactured by and is sold under the responsibility of Versuni Holding B.V., and Versuni Holding B.V. is the warrantor in relation to this product.

(07/2026)



100% 
www.home.id