





KENWOOD

KXT754GL

Instructions





English

The KXT754GL glass bowl has been designed for use on TYPE KMX75/ TYPE KMX76 stand mixer Ver: A Models only.

To check which model Stand Mixer you have, check the rating plate on the underside of your machine.

Safety

- **Before using ensure that your bowl tools are adjusted to the correct height and not in contact with the bottom of the bowl – refer to ‘Adjusting the bowl tool’ section in your main Stand Mixer or relevant attachment instruction manual.**

To avoid damage to the glass bowl;

- Do not allow the bowl to come in contact with sources of high heat such as an oven or stove top.
- Do not hit tools on the side of the bowl to remove ingredients.
- Refer to your main Stand Mixer instruction manual for additional safety warnings and using your bowl.

Special Care Instructions

Glass is a natural material, during the manufacture of this bowl every care has been taken to ensure a perfect appearance, however some small imperfections may be visible, this is normal and to be expected, the performance of the bowl will not be affected.

Service and customer care

- For Service and Customer Care information refer the main manual for your Stand Mixer model or visit www.kenwoodworld.com.
- Designed and engineered by Kenwood in the UK.
- Made in China.

Kenwood Ltd

New Lane
Havant
Hampshire
PO9 2NH

kenwoodworld.com

